





R 153 S
R 153 S3
R 153 S3 BBC



Electrolux

Libretto d'istruzione e uso
Notice d'instructions et mode d'emploi
Instruction manual
Bedienungsanleitung
Manual de uso y manutencion
Gebruiksaanwijzing
Livro de instruções e modo de emprego
Instrukcja obsługi i konserwacji
Használati utasítás
Návod k používání
Brugsvejledning
Bruksanvisning
Bruks- og vedlikeholdsveiledning
Käyttöohjeet
Navodila za uporabo in vzdrževanje
Εγχειρίδιο οδηγιών χρήσης
Eksplotavimo instrukcija



Rasaerba con motore a scoppio - Lama 53 cm

Tondeuse avec moteur à explosion - Lame 53 cm.

Lawn mower with petrol engine - 53 cm blade

Rasenmäher mit Explosionsmotor - Messer 53 cm

Cortadora de hierba con motor de explosión - Cuchilla 53 cm.

Grasmaaimachine met verbrandingsmotor - Mes 53 cm.

Cortagrama com motor a explosão - Lamina 53 cm.

Kosiarka do trawy z silnikiem gazowym – Noż 53 cm.

Robbanò-motor hajtàsù fűnyíró - Kés 53 cm

Sekačka na trávu se spalovacím motorem - žací nůž 53 cm

Plæneklipper med benzinmotor - 53 cm klinge

Gräsklippare med bensinmotor - Kniv 53 cm

Gressklipper med bensinmotor -53 cm kniv

Polttomoottorilla varustettu ruohonleikkuri - leikkuuleveys 53 cm

Motorna kosilnica - rezilo 53 cm.

Clóokoptikhhwhcanhne kinhthra eswterikhg kaushg - Macairi 53 cm.

Vejaipjovë su benzino varikliu - ašmenys 53 sm



Rasaerba semovente
Tondeuse automotrice
Self-propelled lawn mower
Selbstfahrender Rasenmäher
Cortadora de hierba propulsada
Zelfrijdende grasmaaimachine
Cortagrama semovente
Kosiarka do trawy samobieźna
Őnjáró - fűnyíró
Sekačka na trávu s pojezdem
Selvkørende plæneklipper
Sjålvgående gräsklippare
Gressklipper med drift
Vetävä ruohonleikkuri
Kosilnica na avtomatski pogon
Αυτοκίνητη χλοοκοπτική μηχανή
Savaiegë vejaipjovë



Rasaerba semovente 3 velocità
Tondeuse automotrice à 3 vitesses
3-speed self-propelled lawn mower
Selbstfahrender 3-Gang-Rasenmäher
Cortadora de hierba propulsada 3 velocidades
Zelfrijdende grasmaaimachine 3 snelheden
Cortagrama semovente tre velocidades
Kosiarka do trawy samobieźna o 3 prędkościach
Őnjáró - fűnyíró 3 sebességfokozattal
Sekačka na trávu s 3 rychlostmi pojezdu
Selvkørende plæneklipper med 3 hastigheder
Sjålvgående gräsklippare med 3 hastigheter
Gressklipper med drift, 3 hastigheter
Itseliikkuva 3- nopeuksinen ruohonleikkuri
Kosilnica na avtomatski pogon 3 hitrosti
Αυτοκίνητη χλοοκοπτική μηχανή με 3 ταχύτητες
3-ju greičių savaiegë vejaipjovë



Rasaerba semovente 3 velocità con freno lama
Tondeuse automotrice à 3 vitesses avec frein lame
3-speed self-propelled lawn mower with blade brake
Selbstfahrender 3 Gang-Rasenmäher und Messerbremse
Cortadora de hierba propulsada 3 velocidades con freno cuchilla
Zelfrijdende grasmaaimachine 3 snelheden met mesrem
Cortagrama semovente tre velocidades com freio lamin
Kosiarka do trawy samobieźna o 3 prędkościach z hamulcem ostrza
Őnjáró - fűnyíró 3 sebességfokozattal késfékkel
Sekačka na trávu s 3 rychlostmi pojezdu a brzdou žacího nože
Selvkørende plæneklipper med 3 hastigheder og klingebremse
Sjålvgående gräsklippare med 3 hastigheter och broms för kniven
Gressklipper med drift, 3 hastigheter og knivclutch
Vetävä 3-nopeuksinen
Kosilnica na avtomatski pogon s 3 hitrosti in rezilom na zavoro
Αυτοκίνητη χλοοκοπτική μηχανή με 3 ταχύτητες και freno macairiou
3-ju greičių savaiegë vejaipjovë su ašmenų stabdžiais

Il presente manuale rappresenta una parte integrante del prodotto. Vi preghiamo di conservarlo per ogni ulteriore utilizzo.

Le manuel présent fait partie intégrante du produit; nous vous prions en conséquence de le conserver pour toutes nécessités ultérieures.

The present manual constitutes an integral part of the product and it should be kept for all future reference.

Das vorliegende Handbuch gehört zu einem festen Bestandteile des Produktes und muss deshalb zur Einsichtnahme sorgfältig aufgehoben werden.

El presente manual representa una parte integrante del producto. Les rogamos que lo conserven para cualquier ulterior empleo.

Deze handleiding is een integrerend deel van het product. Wij verzoeken u hem te bewaren voor iedere mogelijke nadere raadpleging.

Este manual representa uma parte integrante do produto. Recomendamos guardá-lo para outros usos.

Niniejsza instrukcja stanowi integralną część produktu. Prosimy przechowywać ją do każdego dalszego użytkowania.

A jelen szakkönyv a termék szerves részét képezi. Kérjük megőrizni minden utólagos használatért.

Tato uživatelská příručka je neopomenutelnou součástí výrobku. Uchovávejte ji pro další použití.

Håndbogen er en integreret del af produktet. Den skal opbevares omhyggeligt for yderligere konsultation.

Denna manual utgör en integrerande del av produkten. Vi ber er spara den för senare bruk.

Dette håndbogen representerer en fuldende del af produkten. Det skal opbevares for alle ytre anvendelser.

Tämä käyttöopas kuuluu olennaisena osana tuotteeseen. Säilytä se huolellisesti myöhempää käyttöä varten.

Navodila za uporabo in vzdrževanje so sestavni del izdelka, zato prosimo, da jih shranite in upoštevate za nadaljnjo uporabo.

Το παρόν εγχειρίδιο αποτελεί αναπόσπαστο μέρος του προϊόντος. Σας παρακαλούμε να το φυλάξετε με προσοχή για κάθε παρατεταμένη χρήση.

Šis vadovėlis sudaro neatmetama gaminio dalį ir turi būti išsaugotas tam, kad ateityje galima būtų duoti bet kurtas užklaudas

IT

FR

EN

DE

ES

NL

PT

PL

HU

SK

CZ

DK

SE

NO

FI

SL

GR

LV

La ringraziamo per la fiducia accordataci con l'acquisto del nostro rasaerba. Siamo certi che avrà modo di apprezzare nel tempo e con soddisfazione la qualità del nostro prodotto. La preghiamo di leggere attentamente questo manuale predisposto appositamente per informarla circa il suo uso corretto in conformità ai requisiti essenziali di sicurezza.

Nous vous remercions de la préférence que vous nous avez accordée en choisissant notre tondeuses. Nous sommes persuadés que vous pourrez apprécier dans le temps la qualité de notre produit et que vous en serez entièrement satisfaits. Nous vous prions de lire attentivement ce manuel, spécialement conçu pour illustrer l'utilisation correcte de cette machine, dans le respect des normes de sécurité fondamentales.

We wish to thank you for choosing our lawn mowers. We are confident that the high quality of our machine will meet with your satisfaction and appreciation and that your lawn mower will give you long-lasting service. Before starting to use your machine, make sure to read with care this manual, which has been purposely drawn up to provide you with all the necessary information for proper use, in compliance with basic safety requirements.

Wir danken Ihnen für Ihr Vertrauen, das Sie uns durch den Kauf unseres Rasenmäher entgegengebracht haben und sind sicher, daß Sie mit der Qualität unseres Produkte zufrieden sein werden. Wir bitten Sie, dieses Handbuch aufmerksam durchzulesen, das Sie über die richtige Verwendung in Übereinstimmung mit den Sicherheitsvorschriften informiert.

Le damos las gracias por la confianza que nos ha demostrado al comprar nuestro cortacésped. Estamos seguros de que podrá apreciar con el tiempo y con satisfacción la calidad de nuestro producto. Le rogamos lea atentamente este manual preparado expresamente para informarle sobre el uso correcto con arreglo a los requisitos básicos de seguridad.

Wij danken u voor het vertrouwen waarmee voor u onze maaimachine heeft gekozen. U zult langdurig plezier hebben van de kwaliteit van dit produkt. Leest u aandachtig dit handboek, dat speciaal bedoeld is om u te informeren over het juiste gebruik ervan volgens de vereiste veiligheidsvoorwaarden.

Agradecemos a preferência que nos deram, escolhendo a nossa cortadores de relva. Estamos seguros que, com o tempo, poderei apreciar a qualidade dos nossos produtos e ficarei plenamente satisfeitos. Pedimos a leitura atenta deste manual, preparado especialmente para informar da utilização correcta da máquina e das normas de segurança fundamentais.

Gratulujemy Państwa zakupu naszej kosiarke do trawy jesteśmy pewni, że będziecie Państwo usatysfakcjonowani wysoką jakością naszego produktu. Prosimy o uważne przeczytanie całej instrukcji obsługi i szczególnie uważne zapoznanie się ze wskazaniami dotyczącymi bezpieczeństwa użytkowania urządzenia.

Köszönjük Fünyírógép megvásárlása útján belékhelyezett bizalmat. Biztosak vagyunk, hogy meg lesz elégedve gyártmányunk minőségével. Kérjük, olvassa el figyelemmel ezt az utasítást a helyes használati mód és a biztonság eloirások betartása érdekében.

Děkujeme za Vaši důvěru, kterou jste projevili nákupem naší sekačky na trávu. Jsme přesvědčeni, že vysoká kvalita našich výrobků splní Vaše očekávání a sekačka Vám bude spolehlivě sloužit po dlouhou dobu. Než sekačku nastavíte, přečtěte si pozorně tento návod k používání, který Vám poskytne všechny nezbytné informace týkající se použití stroje v souladu se základními bezpečnostními předpisy.

Vi takker dig for at have valgt en af vores plæneklippere. Vi er overbeviste om, at maskinens høje kvalitet og præstationer vil tilfredsstille dine forventninger og klippe din plæne lang tid fremover. Læs vejledningen grundigt igennem, da den indeholder vigtige råd til en korrekt anvendelse i overensstemmelse med de vigtigste sikkerhedskrav.

Vi tackar er för det förtroende ni visat oss genom att köpa vår gräsklippare. Vi är övertygade om att ni med tillfredsställelse kommer att uppskatta vår produkts kvalitet under en lång tid framöver. Vi ber er om noggrann läsning denna bruksanvisning som har till uppgift att informera er om hur man ska använda gräsklipparen på ett korrekt sätt i enlighet med nödvändiga säkerhetskrav.















Takk for tilliten du har vist ved å kjøpe vår gressklipper. Vi er sikker på at du i fremtiden vil sette pris på og ha glede av kvaliteten til vårt produkt. Vi ber deg om å lese denne veiledningen for å få all informasjon om riktig bruk i overensstemmelse med de viktigste sikkerhetskravene.

Kiitämme ruohonleikkurimme valinnasta. Olemme varmoja, että tuotteemme tarjoaa parhaan mahdollisen suorituskyvyn ja kestää käytössä pitkään. Me käyttööps huolellisesti, sillä se antaa tärkeää laitteen oikeaan ja turvalliseen käyttöön liittyvää tietoa.

Spoštovani kupec, zahvaljujemo se Vam za nakup enega naših proizvodov in Vam želimo veliko zadovoljstva pri delu z novo kosilnico. Preden pričnete z uporabo kosilnice, pozorno preberite navodila, predstavljena v tem priročniku, da bi spoznali in razumeli njegovo vsebino glede pravilne uporabe kosilnice in temeljnih varnostnih ukrepov pri delu.

Sa; eucarisoume gia tin protinsh poume; deikate agorazonta; tin cl oookotikh na; nancianoElnste bekaioti crhsimpoiouta; tin qa mporesete na ektinshete me eucarishtin tin poietha tou proiouto; na; Sa; parakolonne na diabasete prosektikato egeciridio autoupooutoouta; epithete; gia na Sa; plihroforeti katavestwotrope oson af oravthn swesthrish th; mican; sunfwa me tou; basikou kanoue; aspalietia.

Mes esame dekingi Jums už tai, kad Jūs pasirinkote mūsų vejaprovę. Mes esame įsitikinę, kad mūsų mašinoms auktis kokybę užtikrins Jūsų poreikius ir kad Jūsų vejaprovę ilgai Jums tarnaus. Prieš pradėdami naudotis vejaprove, gerai išstudijuokite šią instrukciją, kuri tikslingai buvo sukurta tam, kad apibrėžtų šios reikalingomis duomenimis vejaprovęs naudojimui ir pagrindinių saugos reikalavimų

 	 	 		
 	 	 		
<p>1</p> <p>Attenzione! Leggere il manuale di istruzioni prima dell'uso</p> <p>Attention! Lire le manuel d'instructions avant utilisation.</p> <p>Caution! Read the instruction manual before use.</p> <p>Achtung! Vor der Verwendung ist die Bedienungsanleitung zu lesen.</p>	<p>Atención! Leer el manual de instrucciones antes del uso.</p> <p>Pas op! De gebruiksaanwijzing voor het gebruik nauwkeurig doorlezen.</p> <p>Atenção! Ler o manual de instruções antes do uso.</p> <p>Uwaga! Przed użyciem przeczytać instrukcję obsługi.</p>	<p>Figyelem! Először az utasításokat a használat előtt.</p> <p>Upozornění! Než začnete sekačku používat, pozorně si prostudujte návod k používání.</p> <p>Forsigtig! Læs vejledningen igennem inden ibrugtagning.</p> <p>Varning! Läs bruksanvisningen innan ni använder gräsklipparen</p> <p>Advarsel! Les bruksveiledningen før bruk.</p>	<p>Huomio! Le käyttööps huolellisesti ennen laitteen käyttöönottoa.</p> <p>Pozor! Pozorno preberite navodila preden pričnete z uporabo kosilnice.</p> <p>Prosoch! Diabaste prosektikato egeciridio odhvia priu apu tin crhs.</p> <p>Dmesio! Perskatykite šią instrukciją prieš pradėdami naudojimą.</p>	<p>Älä anna asiattomien henkilöiden oleskella vaara-alueella!</p> <p>Oddalajte tuje osebe iz delovnega območja kosilnice!</p> <p>Apomkrumete ta asceta prosowa apo ton cwo kinhou.</p> <p>Pasiripinkit, kad tarp kitų įėjimų ir pavoingos zonos būtų saugos atstumas.</p>
<p>2</p> <p>Tenere le persone estranee fuori dalla zona di pericolo!</p> <p>Eloigner toute personne étrangère de la zone dangereuse!</p> <p>Keep other people well away from the danger area!</p> <p>Unbefugte dürfen nicht in den Gefahrenbereich gelangen!</p>	<p>Mantener al personal ajeno fuera de la zona de peligro!</p> <p>Zorg ervoor dat andere personen buiten de gevaarzone blijven!</p> <p>Manter pessoas estranhas fora da zona de perigo</p> <p>Osoy postonnie nie powinny przebywać w zasięgu pracy urządzenia.</p>	<p>A veszélyes területen ne tartózkodjanak idegenek!</p> <p>V nebezpečné vzdálenosti se nesmí zdržovat cizí osoby!</p> <p>Hold uvekkommende personer på sikker afstand af farezonen!</p> <p>Håll alla obehöriga på avstånd från riskområdet!</p> <p>Hold uvekkommende utenfor faresonen!</p>	<p>Älä anna asiattomien henkilöiden oleskella vaara-alueella!</p> <p>Oddalajte tuje osebe iz delovnega območja kosilnice!</p> <p>Apomkrumete ta asceta prosowa apo ton cwo kinhou.</p> <p>Pasiripinkit, kad tarp kitų įėjimų ir pavoingos zonos būtų saugos atstumas.</p>	<p>Älä anna asiattomien henkilöiden oleskella vaara-alueella!</p> <p>Oddalajte tuje osebe iz delovnega območja kosilnice!</p> <p>Apomkrumete ta asceta prosowa apo ton cwo kinhou.</p> <p>Pasiripinkit, kad tarp kitų įėjimų ir pavoingos zonos būtų saugos atstumas.</p>
<p>3</p> <p>Attenzione! pericolo ferimento mani e piedi.</p> <p>Attention! Danger de blessures des mains et des pieds.</p> <p>Warning: Risk of hand and feet injury.</p> <p>Achtung: Hand- und Fussverletzung</p>	<p>Atención: peligro heridas a manos y pies.</p> <p>Let op, gevaar voor verwondingen aan handen en voeten.</p> <p>Atenção, perigo machucamento mãos e pés.</p> <p>Uwaga, wirujący nóż niebezpieczeństwo zranienia rąk i nóg.</p>	<p>Figyelem, veszély: kezek és lábak megsebzése.</p> <p>Pozor, nebezpečí poranění rukou a nohou.</p> <p>Forsigtig! Fare for tilføjelse af sår på hænder og fødder.</p> <p>Varning: risk för skada på händer och fötter.</p>	<p>Advarsel: Fare for å skade hendene og føttene.</p> <p>VAROITUS! käsien ja jalkojen loukaantumisen vaara.</p> <p>Pozor! Nevornost poškodob rúk i nog.</p> <p>Prosoch! Kuidno; traumatisuomercivua kai podiva.</p> <p>Įspėjimas: Tra rankų ir kojų traumas rizika.</p>	<p>Advarsel: Fare for å skade hendene og føttene.</p> <p>VAROITUS! käsien ja jalkojen loukaantumisen vaara.</p> <p>Pozor! Nevornost poškodob rúk i nog.</p> <p>Prosoch! Kuidno; traumatisuomercivua kai podiva.</p> <p>Įspėjimas: Tra rankų ir kojų traumas rizika.</p>
<p>4</p> <p>Pericolo di aspirazione di gas tossici! Non utilizzare l'apparecchio in ambienti chiusi o poco ventilati.</p> <p>Danger d'inhalation de gaz toxiques! Ne pas utiliser l'appareil dans des espaces fermés ou peu ventilés.</p> <p>Risk of breathing in toxic gases! Do not use the appliance in closed or poorly ventilated environments.</p> <p>Gefahr des Einatmens giftiger Gase! Das Gerät darf nicht in geschlossenen oder schlecht belüfteten Räumen verwendet werden.</p> <p>Peligro de aspiración de gases tóxicos! No utilizar el aparato en ambientes cerrados o poco ventilados.</p>	<p>Gevaar voor inademing van giftige gassen! Gebruik het apparaat niet in gesloten of niet goed geventileerde ruimtes.</p> <p>Perigo de aspiração de gás tóxicos! Não utilizar o aparelho em lugares fechados ou pouco ventilados.</p> <p>Niebezpieczeństwo wdychania gazów trujących! Nie używać urządzenia w pomieszczeniach zamkniętych lub o słabym przewietrzeniu.</p> <p>Mérgezo gázak belégzése veszély! Ne használni a gépet zárt vagy kevésbé szellőztetett helyiségekben.</p>	<p>Nebezpečí vdechování toxických plynů! Výrobek nesmí být používán v uzavřených nebo nedostatečně větráných prostorech.</p> <p>Fare for indånding af giftige gasser! Anvend andrig maskinen i lukkede eller dårligt ventilerede lokaler.</p> <p>Risk for inånding av giftiga gaser! Använd inte apparaten i stängda eller dåligt ventilerade lokaler.</p> <p>Fare for å puste inn giftige gasser! Ikke bruk apparatet i lukkede eller dårlig ventilerte lokaler.</p>	<p>Myrkyllisten kaasujen hengittämisen vaara! Älä käytä laitetta suljetuissa tai riittämättömästi ilmastoiduissa tiloissa.</p> <p>Nevornost vdihavanja strupenih izpušnih plinov! Nikoli ne uporabljajte kosilnice v zaprtim ali slabo zrancenem prostoru.</p> <p>Kuidno; eischno toikou aeriva. Mh crhsimpoietha thn suskeuhse kl eisuto; hd ipo aerizomoucwrou.</p> <p>Yra mduodų dujų įkvėpimo rizika! Nenaudokite prietaisą uždarytose ar blogai vėdinamose patalpose.</p>	<p>Myrkyllisten kaasujen hengittämisen vaara! Älä käytä laitetta suljetuissa tai riittämättömästi ilmastoiduissa tiloissa.</p> <p>Nevornost vdihavanja strupenih izpušnih plinov! Nikoli ne uporabljajte kosilnice v zaprtim ali slabo zrancenem prostoru.</p> <p>Kuidno; eischno toikou aeriva. Mh crhsimpoietha thn suskeuhse kl eisuto; hd ipo aerizomoucwrou.</p> <p>Yra mduodų dujų įkvėpimo rizika! Nenaudokite prietaisą uždarytose ar blogai vėdinamose patalpose.</p>
<p>5</p> <p>Pericolo di esplosione! Non effettuare rabbocchi di carburante con motore in moto.</p> <p>Danger d'explosion! Ne pas faire le plein de carburant, moteur en marche.</p> <p>Risk of explosion! Do not top up with fuel with engine running.</p> <p>Explosionsgefahr! Treibstoff darf nicht bei laufendem Motor nachgefüllt werden.</p>	<p>Peligro de explosión! No rellenar con carburante cuando el motor está encendido</p> <p>Gevaar voor explosie! Vul geen brandstof met draaiende motor bij.</p> <p>Perigo de explosão! Não juntar o carburante com o motor em função</p> <p>Niebezpieczeństwo wybuchu! Nie przelewać paliwa przy zapalonym silniku</p>	<p>Robbanásveszély! Ne hajtani végre az uzemanyag toltést amikor a motor működésben van.</p> <p>Nebezpečí výbuchu! Pohonné hmoty je zakázáno doplňovat pokud je motor v chodu.</p> <p>Eksplosionsfare! Fyld aldrig brændstof på med motoren løst.</p> <p>Risk for explosion! Utfør inte påfyllning av bränsle med motorn igång.</p>	<p>Fare for eksplosjon! Ikke etterfyll drivstoff med motoren i gang.</p> <p>Rådhjdyksen vaara! Älä suorita polttoaineentäydennystä moottorin käydessä.</p> <p>Nevornost eksplozije! Ne nalivajte gorivo v kosilnico, ko motor deluje.</p> <p>Kuidno; ektrhxh! Mh bazete ta kausim me ton kinhou apo kinsh.</p> <p>Sprogimo rizika! Nepilkit degaliu motoro darbo metu.</p>	<p>Fare for eksplosjon! Ikke etterfyll drivstoff med motoren i gang.</p> <p>Rådhjdyksen vaara! Älä suorita polttoaineentäydennystä moottorin käydessä.</p> <p>Nevornost eksplozije! Ne nalivajte gorivo v kosilnico, ko motor deluje.</p> <p>Kuidno; ektrhxh! Mh bazete ta kausim me ton kinhou apo kinsh.</p> <p>Sprogimo rizika! Nepilkit degaliu motoro darbo metu.</p>
<p>6</p> <p>Attenzione! Superficie calda.</p> <p>Attention! Surface chaude</p> <p>Caution! Hot surface</p> <p>Achtung! Oberfläche ist heiß.</p> <p>Atención! Superficie caliente</p>	<p>Pas op! Warm oppervlak</p> <p>Atenção! Superfície quente</p> <p>Uwaga! Powierzchnia gorąca</p> <p>Figyelem! Meleg felület.</p>	<p>Výstraha! Horký povrch.</p> <p>Forsigtig! Varm overflade.</p> <p>Varning! Mycket het yta.</p> <p>Advarsel! Varm overflate</p>	<p>VAROITUS! Kuuma pinta.</p> <p>Pozor! Vroca površina.</p> <p>Prosoch! Epifanea gernhu</p> <p>Dmesio! Karštas paviršius.</p>	<p>VAROITUS! Kuuma pinta.</p> <p>Pozor! Vroca površina.</p> <p>Prosoch! Epifanea gernhu</p> <p>Dmesio! Karštas paviršius.</p>
<p>7</p> <p>Attenzione! Spegner il motore e staccare la candela prima di effettuare qualunque manutenzione</p> <p>Attention! Eteindre le moteur et enlever la bougie avant d'effectuer quelque opération d'entretien que ce soit.</p> <p>Caution! Switch off the engine and disconnect the spark plug before undertaking any maintenance work.</p> <p>Achtung! Vor der Ausführung jeglicher Wartungsarbeiten ist der Motor abzuschalten und die Zündkerze abzuklemmen.</p>	<p>Atención! Apagar el motor y extraer la bujía antes de efectuar cualquier mantenimiento</p> <p>Pas op! De motor uitzetten en de bougie ontkoppelen alvorens enige onderhoudshandeling uit te voeren.</p> <p>Atenção! Desligar o motor e a vela antes de qualquer manutenção</p> <p>Uwaga! Przed wykonaniem jakiegokolwiek konserwacji zgasić silnik zdjąć przewód ze świecy</p>	<p>Figyelem! Kikapcsolni a motort és kiiktatni a gyertyát minden karbantartási művelet előtt.</p> <p>Výstraha! Před zahájením jakékoli údržby stroje vypněte motor a odpojte kabel ze zapalovací svíčky.</p> <p>Forsigtig! Enhver form for vedligeholdelse skal ske med slukket motor og frakoblet tændrør.</p> <p>Varning! Stäng av motorn och lossa tändstiftet innan något som helst ingrepp för underhåll utförs.</p> <p>Advarsel! Slå av motoren og kople fra tennpluggen før det utføres vedlikehold.</p>	<p>Huomio! Sammuta moottori ja irrota sytytystulpan johto ennen minkään huoltoimenpiteen aloittamista.</p> <p>Pozor! Ugasnite motor in sнемite kabel s svečke pred kakršnemoi vzdrževalnem delu.</p> <p>Prosoch! Shbete tonkinthra kai aposunete to mpouzoi protokante opoiadipote epeshash ston lish.</p> <p>Dmesio! Įjunkti variklį ir atjunkti žvakę prieš pradėdami techninio aptarnavimo darbus.</p>	<p>Huomio! Sammuta moottori ja irrota sytytystulpan johto ennen minkään huoltoimenpiteen aloittamista.</p> <p>Pozor! Ugasnite motor in sнемite kabel s svečke pred kakršnemoi vzdrževalnem delu.</p> <p>Prosoch! Shbete tonkinthra kai aposunete to mpouzoi protokante opoiadipote epeshash ston lish.</p> <p>Dmesio! Įjunkti variklį ir atjunkti žvakę prieš pradėdami techninio aptarnavimo darbus.</p>
<p>8</p> <p>Tenere il cavo di alimentazione lontano dall'utilensile tagliente.</p> <p>Ecarter le câble d'alimentation de l'outil tranchant.</p> <p>Keep the power supply cable well away from the cutting tool.</p> <p>Das Speisekabel darf nicht in den Bereich des Schneidwerkzeuges gelangen.</p>	<p>Mantener el cable de alimentación lejos de la herramienta de corte.</p> <p>De voedingskabel op afstand van de maaiinrichting houden.</p> <p>Manter pessoas estranhas fora da zona de perigo.</p> <p>Przewód zasilający nie może znajdować się w zasięgu pracy noża.</p>	<p>A veszélyes területen ne tartózkodjanak idegenek! Zákaz zadržania sa cudích osob v nebezpečnej oblasti.</p> <p>Strømtilførselskablet må ikke være i nærheten af skæreredskabet.</p> <p>Håll matningskabeln på säkert avstånd från klippningsverktyget.</p> <p>Hold strømtekkelen i god avstand fra kniven.</p>	<p>Pidä virtajohto kaukana leikkaavasta terästä.</p> <p>Vedno ohranite razdaljo med elektrinim kablom in rezilom.</p> <p>Kratate to trofodotikovkvaldio makiavapo to kof terovergaleio.</p> <p>Laikykite maitinimo šaltinio kabelį toliau nuo pjauančio instrumento.</p>	<p>Pidä virtajohto kaukana leikkaavasta terästä.</p> <p>Vedno ohranite razdaljo med elektrinim kablom in rezilom.</p> <p>Kratate to trofodotikovkvaldio makiavapo to kof terovergaleio.</p> <p>Laikykite maitinimo šaltinio kabelį toliau nuo pjauančio instrumento.</p>
<p>9</p> <p>Attenzione! Proteggere dalla pioggia e dall'umidità.</p> <p>Attention! Protéger de la pluie et de l'humidité.</p> <p>Caution! Shelter from rain and humidity.</p> <p>Achtung! Vor Regen und Nässe schützen.</p> <p>Atención! Proteger de la lluvia de la humedad.</p>	<p>Voorzichtig! Beschermen tegen regen en vocht.</p> <p>Atenção! Proteger contra a chuva e a humidade.</p> <p>UWAGA! Zabezpieczyć przed deszczem i wilgocią.</p> <p>Figyelem! Ővni az esőtól és a nedvességtől.</p>	<p>POZOR! Charate před deštěm a vlhkem.</p> <p>BEMERK! Skai beskyttes mod regn og fugtighed</p> <p>Varning! Skyddas från regn och fukt.</p> <p>Pas pā! Beskyttelse mod regn og fugtighed.</p>	<p>Varoitus! Suojele sateelta ja kosteudelta.</p> <p>Pozor! Zaščitite pred dežjem in vlažnostjo.</p> <p>Προσοχή! Προστατεύστε από την βροχή και την υγρασία.</p> <p>Dmesio! Uždenkit nuo lietaus ir drėgmės.</p>	<p>Varoitus! Suojele sateelta ja kosteudelta.</p> <p>Pozor! Zaščitite pred dežjem in vlažnostjo.</p> <p>Προσοχή! Προστατεύστε από την βροχή και την υγρασία.</p> <p>Dmesio! Uždenkit nuo lietaus ir drėgmės.</p>
<p>10</p> <p>Prima di qualsiasi intervento sull'utensile tagliente togliere la spina di alimentazione</p> <p>Deconnecter la fiche avant d'intervenir sur l'outil tranchant</p> <p>Before carrying out any operations on the cutting tool, disconnect the plug</p> <p>Vor jeglicher Arbeit am Schneidwerkzeug den Stecker abnehmen</p>	<p>Antes de intervenir en la herramienta de corte quitar la clavija</p> <p>Voor alle onderhoudswerkzaamheden aan de snijinrichting de stekker uittrekken</p> <p>Afastar o cabo de alimentação da parte de corte.</p> <p>Przewód zasilający nie powinien znajdować się w zasięgu pracy noża.</p> <p>Elektromos kábelat a pengétől távolartan</p>	<p>Elektrická šňúra musí být d'aleko od rezacího nástroja.</p> <p>Tag stikket ud af stikkontakten, inden der røres ved kniven.</p> <p>Innan något som helst ingrepp på klippningsverktyget sker, tag ut kontakten för elektrisk matning.</p> <p>Ta av tilføringsteppelen for alle inngrepene på verketøyet.</p>	<p>Irota pistotulppa pistorasista ennen minkään leikkau-laitteeseen tehtävän toimenpiteen suorittamista.</p> <p>Ugasnite motor in sнемite elektrinim kabel pred kakršnemoi vzdrževalnem delu.</p> <p>Protokante to opoiadipote epeshash sto kof terovergaleio bzagete to fi; trofodotioac.</p> <p>Prieš pradėdami bet kurios veiksmo pjauniančiu instrumentu atjunkite maitinimo laidą.</p>	<p>Irota pistotulppa pistorasista ennen minkään leikkau-laitteeseen tehtävän toimenpiteen suorittamista.</p> <p>Ugasnite motor in sнемite elektrinim kabel pred kakršnemoi vzdrževalnem delu.</p> <p>Protokante to opoiadipote epeshash sto kof terovergaleio bzagete to fi; trofodotioac.</p> <p>Prieš pradėdami bet kurios veiksmo pjauniančiu instrumentu atjunkite maitinimo laidą.</p>

DESCRIPTION)				
A	1	Upper handles	7	Deck
	2	Fuel-enrichment pump	8	Adjusting levers for cutting height
	3	Fastening knobs for upper handles	9	Spark plug
	4	Grass catcher	10	Fuel cap
	5	Oil filler cap	11	Engine start-grip
	6	Oil drain plug	12	Rear deflector
			13	Throttle lever
			14	Engine stop lever
			15	Reduction gear
			16	Console
			17	Clutch lever
			18	Blade engagement lever
			19	Handle advance speed

B ASSEMBLY OF GRASS CATCHER

C ASSEMBLY



Self-Propelled Lawnmower.

Remove the bail arms, attach cables as shown and re-fit the bail arms.

D ASSEMBLY



3 Speed Self-Propelled Lawnmower.

Remove the bail arms, attach cables as shown and re-fit the bail arms.

E ASSEMBLY



3 Speed Self-Propelled Lawnmower with Blade Brake.

Remove the bail arms, attach cables as shown and re-fit the bail arms.

F MULCHING CAP INSERTION)

To cut the grass with the mulching system (no grass collection), lift the rear deflector panel and insert the cap by fixing it with the spring as shown in the figure.

G ADJUSTMENT OF HANDLES HEIGHT

H ADJUSTMENT OF CUTTING HEIGHT

I SAFETY PRECAUTIONS



- Always operate with the deflector or grasscatcher in the correct position.
- Always stop the engine before removing the grasscatcher or adjusting the height of cut.
- Never place your hands or feet underneath the deck or into the rear grass discharge chute while the engine is running.

J Before mowing, remove all foreign objects from the lawn which may be thrown by the machine. While mowing, stay alert for any foreign objects which may have been missed.
Never lift the rear of the mower while starting the engine or during normal operation.

K Never place your hands or feet underneath the deck or into the rear discharge chute while the engine is running.

L OPERATION

ENGINE ADJUSTMENTS

Refer to the engine manufacturer's maintenance manual.

CAUTION: - 0.6l Oil must be added to the engine before use.

M STARTING THE ENGINE

Once the machine has been set up properly, start the engine as follows:

a) Engines with choke system:

when the engine is cold, position the accelerator lever (13) on START

b) Operate the engine stop lever (14) to prepare the engine for start, keep lever pressed against handle while starting and using the machine - it operates the engine brake.

c) Engines with primer system:

Press the fuel-enrichment pump (2) located on the carburettor 3 or 4 times position the accelerator lever (13) on MAX.

For further information and explanations, read carefully the user instruction manual of the engine.

d) Start engine.

MANUAL STARTING: (While holding the engine stop lever (14)).

• Hold the engine start-grip (11) and pull the starter rope gently until you feel the resistance caused by compression. Return the starter rope slowly then pull the handle firmly towards you to its full extent.



Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops.

MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear.

How to insert automatic advance: Lift up the clutch handle (17) and keep it pressed in position.

CAUTION: Engage the gear only when the engine is running.

How to disengage advance: Release the clutch handle.



Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops.

MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear.

Before proceeding with the coupling of the automatic feed, choose the speed by means of the change lever (19).

Change the speed with the clutch disengaged. There are 3 speed settings.

1°~ 0,6 m/s

2°~ 0,9 m/s

3°~ 1,2m/s

How to insert automatic advance: Lift up the clutch handle (17) and keep it pressed in position.

CAUTION: Engage the gear only when the engine is running.

How to disengage advance: Release the clutch handle.



With engine running, pull the handle (14) towards the bar and keep depressed. Push the blade engagement lever (18) forward to make the blade rotate.

WARNING! When the handle (14) is released the blade stops while the motor continues running.



MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear.

Before proceeding with the coupling of the automatic feed, choose the speed by means of the change lever (19).

Change the speed with the clutch disengaged. There are 3 speed settings.

1°~ 0,6 m/s

2°~ 0,9 m/s

3°~ 1,2m/s

How to insert automatic advance: Lift up the clutch handle (17) and keep it pressed in position.

CAUTION: Engage the gear only when the engine is running.

How to disengage advance: Release the clutch handle.



Important: If, when you press the clutch lever, the automatic advance gear does not engage, the clutch cable should be adjusted by inserting the spring (P) in one of the subsequent holes in the plate (R) or in the hole "S" .



AUTOMATIC ADVANCEMENT

Periodically check the automatic advance assembly and make sure to keep it clean. In particular, the pinion (20) and the gear (21) must be kept perfectly clean. To carry out this check, you must remove the wheel (22) by unscrewing the screw (23).

SAFETY RULES

Training

a) Persons under 16 years of age and persons who are not familiar with the user instructions must not use the lawn mower.

b) The operator is responsible for the safety of other people in the working area. Keep children and domestic animals at a safe distance when the lawn mower is in use.

c) This machine is to be used exclusively for cutting natural grass. Never use the mower for other purposes (e.g., for flattening out bumps in the ground, such as mole-hills or ant-hills).

d) Work only when there is sufficient light.

e) Before mowing, remove all foreign objects from the lawn which may be thrown by the machine. While mowing, stay alert for any foreign objects which may have been missed.

Setting up and operating the lawn mower

a) When mowing, wear strong footwear (boots or heavy shoes) and long trousers.

b) Before you start mowing, make sure that the blade and blade fixing screw are securely fastened. If the blade is damaged, it must be replaced.

c) Turn off the engine, wait until the blade has stopped and remove the spark plug cap before:

- transporting, lifting or moving the machine away from the working area;

- carrying out maintenance or cleaning, or when carrying out any operation on the blade;

- adjusting the cutting height;

- leaving the machine unattended.

Caution! The blade starts turning as soon as the engine is started

d) **Caution!** The fuel is highly inflammable:

- Store fuel in containers specifically designed for this purpose.

- Refuel outdoors only and do not smoke while refueling.

- Fill up the fuel tank before starting the engine. Under no circumstances open the fuel tank cap or add petrol when the engine is running or when it is still hot.

- If the petrol has overflowed, do not under any circumstances start up the engine. Move the mower away from the area where fuel has been spilt and avoid any source of possible ignition until the petrol fumes have dissipated.

- Replace the fuel tank cap and tighten it down firmly.

e) Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect..

f) When mowing, never run; you must always walk.

g) Exercise extreme caution when turning or when pulling the lawn mower towards you.

h) Particular precautions must be taken when mowing on slopes or downhill stretches:

- Use appropriate antislip footwear.

- Always be sure of your footing.

- Mow across the face of slopes, never up or down.

- Take great care when changing direction.

- Do not mow on excessively steep slopes.

i) Never use the lawn mower unless the guards and safety devices (e.g. deflector, grass catcher) are securely in position and in good condition.

j) Ensure that the grass catcher and deflector are correctly located. Failure to do so may result in foreign objects being ejected by the blade.

k) For reasons of safety, the engine must never exceed the speed. (r.p.m.) indicated on the label.

l) Take care when starting the engine and be sure to follow the user instructions. Never place your hands or feet underneath the deck or into the rear discharge chute while the engine is running.

m) Never lift the rear of the mower while starting the engine or during normal operation.

n) If the blade happens to hit any obstacle, stop the engine at once and remove the spark plug cap. Then get an expert to examine the blade.

Maintenance and storage

a) Make sure that all nuts, bolts, and screws are kept well tightened to keep the mower in a safe operating condition.

b) Never leave the machine with fuel in the tank within an enclosed area where the fuel vapours could reach naked flames or sparks.

c) Allow the engine to cool before storing in any enclosure.

d) Keep the engine, silencer, battery compartment and petrol tank free from grass, leaves and excess lubricant, in order to reduce the danger of fire.

e) Frequently check the grass catcher for wear or deterioration

f) For safety reasons, be sure to replace worn-out or damaged parts in due time.

g) If the fuel tank has to be drained, it is essential that this be done outdoor.

h) Assemble the blades following the corresponding instructions and use only blades bearing the maker's name or the trademark of the manufacturer or supplier and marked with the reference number.

i) To protect hands during disassembly or assembly of the blades, it is absolutely essential to wear suitable protective gloves.

U

MAINTENANCE



Caution! Switch off the motor and disconnect the spark plug before undertaking any maintenance work.

- For a four stroke engine, check the oil level and change the oil when dirty. For further explanation, see ENGINE INSTRUCTION BOOK.
- Frequently check the mower and ensure that all grass deposits are removed from beneath the deck.
- Never clean the mower by pouring water over it: this may seriously damage the electric start system.
- Take care, the exhaust muffler may be very hot.
- Frequently remove the wheel screws clean with petroleum and oil before replacing. Ball bearings must be greased before remounting.
- Frequently check the blade for damage.
- The lawn mower must be checked by a SERVICE DEALER.
- Cleaning under the bodywork
 - With machine at a standstill and off.
 - Attach fitting (24) on the deck to the water supply tap. Turn on the tap.
 - start up the motor (blade in rotation), allowing it to warm up for a few minutes.
 - at the end of cleaning switch off the motor, turn off the tap, detach the tube from the deck connection.

BLADE

V





- To remove the blade (25) unscrew the screw (26).
- Check the conditions of the blade-support (27), the washer (28), the key (29) and the washer (31) and replace any parts which are damaged.
- When reassembling, make sure that the key (29) is correctly seated in the shaft and that the cutting edges face in the direction of the engine rotation. The blade screw (26) must be torqued to 5,34 Kgm (52,4 Nm).

W



- To remove the blade (31) unscrew the two screws (32).
- Check the condition of the blade and replace any parts that are damaged, re-assemble using two screws (32) which must be torqued to 5,34 Kgm (52,4Nm).

A**B**

C

2

3


4









5










6








7













1



D**2****3****4****5****6****7****1**

E







Stabilimento e uffici: ELECTROLUX OUTDOOR PRODUCTS - Via Unione, 2/4 - 20015 PARABIAGO (MI) - ITALY

Sede legale: ELECTROLUX OUTDOOR PRODUCTS - Via Como 72 - 32868 VALMADRERA (LC) - ITALY

The Electrolux Group. The world's No.1 choice.

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion in more than 150 countries around the world.



COD. 99991711 - 5312134-95 ED. 12/2004 Q.TY - PRINTED IN ITALY